

Oscilloscope Guide



Turn the oscilloscope on. Here are some useful settings for the o-scope:

Storage → Store must be off.

If you see nothing, try BEAM FIND or turn the intensity button.

Make sure the Channels you are using are ON. Never use X10 cause it makes the signal ten times bigger.

Position knob..

ALWAYS have both channels set on DC.

SEC/DIV> the best setting for testing the blast phones is .5 sec.

Set the MAGnitude on X1.

Good setting to start with is 1V/DIV.